



1. Remove the radiosonde and the de-reeler from their packaging and put the tied de-reeler loop through the radiosonde eye-hook as shown.

*NOTE:*

The de-reeler has a tied loop for attachment to the radiosonde as opposed to a zip tie. The remaining zip tie attaches to the balloon or parachute.

2. Put the tied de-reeler loop through the radiosonde eye-hook as shown.

*NOTE:*

The de-reeler can alternatively be tied to the radiosonde eye-hook.

3. Make a larger loop by pulling some of the de-reeler string through the tied de-reeler loop.

4. Once this loop is big enough, put the de-reeler through this bigger loop.

5. Your de-reeler is now securely fastened to the radiosonde for flight!

